






# PROFINISHER 620



## **Model 620 Replacement Parts**

<b>Part No</b>	<b>Description</b>
762	ProFinisher™ Vacuum, Low Profile 6" PSA Pad
800	Pad Wrench
1320	Hub Lock Ring
1320-1	Spindle Lock Ring
1321-CW	Bearing Plate Washer Only
1342-1	Bearing Spacer
1352-PNV	PR Vac Swivel Comp.
1515	Housing
1519	Crank & Drive Assembly (600 Series)
1520	Lock Ring
1521	Bearing Cup
1523S	Motor Vane Set (5)
1524	Rotor
1528	Cap
1529	Trigger
1530	Air Control Assembly
1541R	Red Air Inlet
1542	Bearing Shield
1544	Spindle
1546	6" Shroud
1552	Muffler
1712-1NS	Lower Spindle Bearing
1712-2NS	Upper Spindle Bearing
1810	Bearing
1810-1NS	Motor Bearing
1820P	Woodruff Key